

Assembly Steps for B&O RR Telegraph Office – O scale version:

- 1 – Assemble entry door, Fig. 1
- 2 – Install all window glass on inner walls, Fig. 2A, 2B, 2C, 2D & 2E
- 3 – Assemble inner walls & floor, Fig. 3
- 4 – Install inner wall assembly to base, Fig. 4
- 5 – Install office counters, & bumpout desk to interior, Fig. 5
- 6 – Install entry door assembly & counter gate, Fig. 6
- 7 – Install foundation panels, Fig. 7
- 8 – Install lower band trim, Fig. 8
- 9 – Install ceiling, Fig. 9
- 10 – Install drop siding, Fig. 10
- 11 – Install sub-window sills & window sills, Fig. 11
- 12 – Install trim, Fig. 12
- 13 – Install stairs, Fig. 13
- 14 – Install roof truss, Fig. 14
- 15 – Install false rafters FR-3, Fig. 15
- 16 – Install false rafters FR-4 series, Fig. 16
- 17 – Install corner false rafters CFR-1, Fig. 17
- 18 – Install corner false rafters CFR-2 series, Fig. 18
- 19 – Install hip rafters HR-1, Fig. 19
- 20 – Install roof panels, Fig. 20